

REAR DIFF FLUID

Just take off the cover by loosening the bolt on both sides of the rear end.
Drain the shipping oil by removing the drain bolt on the bottom of the rear end.

Replace drain bolt. Remove oil fill bolt on top of the rear end.

Fill with 150ml of 90 weight gear oil.

Replace oil fill bolt. Replace rear end cover. And you're ready to go.

Don't forget to adjust the cable to have the slightest bit of slack in it when shifted into forward.